

# SERVICE MANUAL

## YP-D4 STEREO TURNTABLE



SINCE 1887



# YAMAHA

NIPPON GAKKI CO., LTD. HAMAMATSU, JAPAN

004381

PRINTED IN JAPAN 2.79 2.3K

## ■ CONTENTS

SPECIFICATIONS .....	2
INTERNAL VIEW	
1. TOP VIEW .....	3
2. BOTTOM VIEW .....	3
DISASSEMBLY PROCEDURES .....	4
ADJUSTMENTS	
1. MECHANISM ADJUSTMENTS .....	6
2. CIRCUIT BOARD ADJUSTMENTS .....	7
PACKAGE INSTRUCTION .....	7
PARTS LIST .....	8
SCHEMATIC DIAGRAM .....	12
WIRING/PRINTED CIRCUIT BOARDS .....	13


## ■ SPECIFICATIONS

TURNTABLE SECTION	
Motor	8 Pole coreless DC servo Motor
Turntable Platter	30 cm (12") die-cast aluminum 1.1 kg
Speeds	33-1/3 and 45 rpm (2-speeds)
Drive System	Direct drive
Signal-to-Noise Ratio	77 dB (IEC 98A weighted)
Wow and Flutter	± 0.055% Peak (IEC 98A weighted), 0.04 %Wrms
Speed Variation	±4% (Independent for each speed)
TONEARM SECTION	
Type	S-shaped static balanced
Effective length	215 mm (8-1/2")
Overhang	16 mm
Suitable Cartridge Weight	4 to 10 grams
Headshell	Plug-in type to EIA standard
Cartridge	CG6600 (General and Australian model)
GENERAL	
Power Supplies	120 V AC, 60 Hz USA and Canadian
	220 V AC, 50 Hz European, Germany
	240 V AC, 50 Hz British, Australian
	110 – 130/220 – 240 V AC, 50/60 Hz General
Power Consumption	6 Watts
Dimensions (W x H x D)	435 x 140 x 360 mm (17-1/8" x 5-1/2" x 14-1/4")
Weight	8 kg (17.6 lb)
Accessories	EP adaptor Cartridge-retaining screws, Overhang gauge
Exterior Finish	YP-D4 [Ebony] USA and Canadian YP-D4 [Century walnut] European, British, Australian and General

*Specifications subject to change without notice.*


## ■ INTERNAL VIEW

### 1. TOP VIEW



- ① EP ADAPTOR HOLDER
- ② CABINET
- ③ CENTER SHAFT
- ④ CLUTCH PLATE
- ⑤ MAIN GEAR
- ⑥ COUNTER WEIGHT
- ⑦ ARM BASE
- ⑧ INSIDE FORCE CANCELER
- ⑨ ARM REST
- ⑩ TONE ARM
- ⑪ HEAD SHELL
- ⑫ CUEING LEVER
- ⑬ CUT PUSH SWITCH
- ⑭ TURN TABLE GEAR
- ⑮ SPEED ADJUSTING KNOBS
- ⑯ SPEED SELECTOR SWITCHES
- ⑰ STROBE LAMP

### 2. BOTTOM VIEW



- ① FEED ARM
- ② TONEARM CENTER
- ③ MICRO SWITCH
- ④ 5P LUG TERMINAL BOARD
- ⑤ SHIELD COVER
- ⑥ MOTOR
- ⑦ POWER TRANSFORMER
- ⑧ CUE SEESAW
- ⑨ REJECT LEVER
- ⑩ POWER CIRCUIT BOARD
- ⑪ CONTROL CIRCUIT BOARD
- ⑫ VARIABLE RESISTORS  
(5 cor x 2)
- ⑬ SPEED SELECTOR SWITCHES  
MOUNTING BOARD

## DISASSEMBLY PROCEDURES

Before disassembling the unit, remove the platter, dust cover and cartridge, and securely tie the arm to the arm rest with string, etc. Then, gently turn the unit upsidedown and place it on books, etc. piled up on both sides to protect the arm and cabinet from damage.

### 1. Bottom cover Removal

Remove 9 screws then take the rear panel out.  
(Photo 1)




Photo 1

### 2. Tonearm Removal

- Remove the bottom cover. (refer to step 1)
- Remove the lead wires connected to the 5P lug terminal as shown in Fig. 1.




Fig. 1

- Feed arm ass'y is taken off by removing screws ① and ②.




Fig. 2

- Remove the bolts ① to ③ in photo 2 with a hexagonal wrench (4mm) and remove the tone-arm.

When you have changed the tonearm, do adjust the tonearm return and up and down. (Refer to Page 6 ).



Photo 2

### 3. Motor Removal

- Remove the bottom cover. (Refer to step 1)
- Remove the lead-wires connected to the control circuit board.
- Remove the screws ① to ④ and remove the motor.




Photo 3

When mounting the motor, be careful to the followings.

- Mount the motor so that the two gears are at 47mm intervals.
- Mount the motor so that the center of toothless portion of the main gear is directed toward the platter gear.




Fig. 3

#### 4. Control Circuit Board Removal

- Remove the bottom cover. (Refer to step 1)
- Put the circuit holders ① to ③ between a long nose plier in Fig. 4 and remove the control circuit board.




Photo 4




Fig. 4

#### 5. Power Circuit Board Removal

- Remove the bottom cover (Refer to step 1)
- Put the circuit holders ① to ③ in photo 5 between a long nose plier in Fig. 4 and remove the power circuit board.




Photo 5

#### 6. Controls Removal

- Removal of switch mounting board take off the screws ①, ② shown in photo 6.
- Removal of variable resistors take off the screws ③, ④ shown in photo 6.




Photo 6

#### 7. Power Transformer Removal

Remove the screws ① and ② and remove the transformer with a fixture metal.




Photo 7

## ■ ADJUSTMENTS

### I MECHANISM ADJUSTMENTS

#### 1. Adjustment of Auto Return

If there is an excessive gap between the feed arm and the REJECT Lever, adjust the gap. (Refer to Fig. 1)

- A) When there is a small gap
- B) When there is an excessive gap.

1. Adjust the eccentric shaft at middle point.
2. Loosen the set screw of the feed arm and the gap between the feed arm and Reject lever becomes about 7mm and tighten the screw softly.
3. Turn the eccentric shaft and adjust the return operation.




Fig. 1

#### 2. Arm Lifter Height Adjustment

1. Remove the tonearm from the arm rest and putting it on the elevation plate, turn the main gear in 45° range adjust the set screw of the cue seesaw so that the gap between the record surface and the stylus tip becomes about 6mm.

- a) Raising the stylus tip  
Turn the set screw clockwise.
- b) Lowering the stylus tip.  
Turn the set screw counter-clockwise.

2. Turn the main gear counter-clockwise and return at the original point. Turn the screw so that the stylus tip is 4 to 10mm from Record surface.




Fig. 2

## II CIRCUIT BOARD ADJUSTMENTS

### 1. Rotational Speed Adjustment

First set the speed controls "33" and "45" on the upper surface of the body to the center of the variable range. Then, adjust VR2 and VR1 in that order so as to make the specified stroboscope stop at the respective rational speed. Adjust again, using the speed controls.

VR1 : 33 r.p.m.

VR2 : 45 r.p.m.




Fig. 3

### 2. Motor DRIVING wave from Adjustment

Adjust VR3 and VR4 in Fig. 3, connecting the oscilloscope to 7 and 12 terminals on the Control Circuit Board as shown in Fig. 3.






Fig. 4

## ■ PACKAGE INSTRUCTION





## DESTINATION ABBREVIATIONS

R : General   G : North European   A : Australian  
 U : USA      B : British


C : Canadian

\* New Parts

Ref. No.	Part No.	Description	部品名	Markets	Remarks
1	42 00 00 SX 97 20 50	Cabinet (Ebony)	846905	キャビネット	U,C
1	42 00 00 SX 97 20 60	- do. - (Century Walnut)	846905-5	"	G,R,A,B
2	42 00 00 SX 97 20 70	Control Panel	851554	コントロールパネル	

\* New Parts

Ref No.	Part No.	Description	部品名	Markets	Remarks
3	42 00 00 SX 97 20 80	Lamp Cover	ランプカバー		
4	42 00 00 SX 97 20 90	Selector Lever	切換えレバー		
5	42 00 00 SX 97 21 00	Reject Button Assembly	リゼクトボタンAss'y		
6	42 00 00 SX 97 21 10	Reject Lever	リゼクトレバー		
7	42 00 00 SX 97 21 20	Variable Resistor	ポリューム		
8	42 00 00 SX 97 21 30	Knob VR	VRツマミ		
9	42 00 00 SX 97 21 40	Push Switch	プッシュスイッチ		
10	42 00 00 SX 97 21 50	SP Botton Assembly	SPボタンAss'y		
11	42 00 00 SX 97 21 60	Rest Stand	レストダイ		
12	42 00 00 SX 97 21 70	PU Assembly	PUAss'y		
12-a	42 00 00 SX 97 21 80	Counter Ring	カウンターリング		
12-b	42 00 00 SX 97 21 90	Main Weight	メインウェイト		
12-c	42 00 00 SX 97 22 00	Head Shell	ヘッドシェル		
12-d	42 00 00 SQ 06 02 10	Cartridge CG-6600	カートリッジ	Only Rand A markets	
13	42 00 00 SX 97 22 20	Elevation Plate	エレベーションプレート		
14	42 00 00 SX 97 22 40	Feed Arm Assembly 2	送りアームAss'y 2		
15	42 00 00 SX 97 23 70	Neon Lamp	ネオンランプ		
16	42 00 00 SX 97 23 90	SR Bushing	SRブッシング		
17	42 00 00 SX 97 24 00	AC Cord Stopper	電源止め金具		
18	42 00 00 SX 97 14 00	Lock Plate	ロックプレート		
19	42 00 00 SX 97 14 10	Dust Cover Assembly	ダストカバーAss'y		
20	42 00 00 SX 97 24 40	Turn Table	ターンテーブル		
21	42 00 00 SX 97 24 50	Turn Table Seat	ターンテーブルシート	U	
21	42 00 00 SX 97 24 60	- do. -	"	C,G,R,B,A	
22	42 00 00 SX 97 24 70	Adaptor Shaft	アダプター軸		
23	42 00 00 SX 97 24 80	EP Adaptor	EPアダプター		
24	42 00 00 Ei 03 00 80	Screw BT +	3 x 8		
25	42 00 00 Ei 03 01 60	Screw BT +	3 x 16		
26	42 00 00 EV 90 03 20	Washer FW φ3.2 x φ13 x t0.8			
27	42 00 00 EA 02 00 40	Screw FM +	2 x 4		
28	42 00 00 SX 97 15 00	Washer BW φ4.5 x φ9.8 x t0.5			
29	42 00 00 EZ 00 04 80	Bolt M4 x 18	六角孔付ボルト		
30	42 00 00 SX 97 15 10	Screw FT -	2.6 x 4		
31	42 00 00 EZ 00 08 70	Bolt M3 x 6			
32	42 00 00 SX 97 15 40	Screw TPM +	3 x 14		
33	42 00 00 SX 97 15 50	Screw WM +	3.1 x 16		
34	42 00 00 ED 34 00 80	Screw Truss +	4 x 8		
35	42 00 00 SX 97 12 50	Click Spring	クリックバネ		
36	42 00 00 SX 97 13 10	Button Spring	ボタンスプリング		
37	42 00 00 SX 97 25 10	REJ Spring	REJスプリング		
38	42 00 00 SX 97 25 20	ARM Spring	アームバネ		
39	42 00 00 SX 97 23 00	Power Cord	電源コード	U,C,R	
39	42 00 00 SX 97 23 10	- do. -	"	G	
39	42 00 00 SX 97 23 20	- do. -	"	B	
39	42 00 00 SX 97 23 30	- do. -	"	A	
	42 00 00 KB 00 10 10	Fuse 0.5A, 250V	ヒューズ 0.5A, 250V	U,C	
	42 00 00 KB 00 07 10	- do. -	"	G,B,A	
	42 00 00 KB 00 03 10	- do. -	"	R	
	42 00 00 SX 97 25 30	Fuse 0.1A, 250V	ヒューズ 0.1A, 250V	U,C	
	42 00 00 KB 00 06 10	- do. -	"	G,R,B,A	
	42 00 00 SX 97 23 40	Spark Killer Cap.	スパークキラーコンデンサ	U	
	42 00 00 SX 97 23 50	- do. -	"	C	
	42 00 00 SX 97 23 60	- do. -	"	G,R,B,A	




◆ New Parts


# SCHEMATIC DIAGRAM

A


B


C





## ■ WIRING/PRINTED CIRCUIT BOARDS





• WIRE COLOR ABBREVIATIONS

BL ▶ Black	VI ▶ Violet
BR ▶ Brown	GY ▶ Gray
RE ▶ Red	WH ▶ White
OR ▶ Orange	GG ▶ Grass Green
YE ▶ Yellow	SB ▶ Sky Blue
GR ▶ Green	PK ▶ Pink
BE ▶ Blue	