AM/FM STEREO RECEIVER

SX-550

HG

PIONEER

SWITCHES;
S_1 SPEAKERS
1. POWER OFF
2. SP A
3. SP OFF
4. SP B
5. SP A+B

S_2 FM MUTING
ON — OFF

S_3 MODE
STEREO — MONO

S_4 TAPE MONITOR 1
OFF — ON

S_5 TAPE MONITOR 2
OFF — ON

S_6 LOUDNESS
OFF — ON

S_7 AC VOLTAGE SELECTOR
220V — 240V

S_8 FUNCTION
1. AM
2. FM
3. PHONO
4. AUX/MIC

RESISTORS;
IN OHM, 1/4W, ±5% TOLERANCE UNLESS OTHERWISE NOTED K : kΩ M : MΩ

CAPACITORS;
IN μF UNLESS OTHERWISE NOTED P : pF

[V] : SIGNAL VOLTAGE NECESSARY OBTAINING 14V/8Ω OUTPUT POWER (1K Hz)

V : DC VOLTAGE AT NO INPUT SIGNAL.

RF ASS'y AWE-072

AF MUT ASS'y AWM-101

AF Ass'y AWK-061

VR1 TREBLE
VR2 BALANCE CONTROL
VR3 VOLUME CONTROL
VR4 BASS

Q1 2SK55
Q2 2SC535
Q3 2SC461
Q4 HA1137
Q5 HA1156W-P
Q6 2SC945
Q7, Q8 2SA725 x2
Q9 HA1138
Q10, Q11 TA7136P1 x2
Q12, Q13 2SC1312
Q14, Q15 2SA725 x2
Q16, Q17 2SC1312 x2
Q1, Q2 2SK30AW
Q3 2SC945A
Q4 2SA733
Q1 2SA798
Q2 2SA798
Q3, Q4 2SC1438 x2
Q5, Q6 2SC1211 x2
Q7, Q8 2SA697 x2
Q9, Q10 2SD526 x2
Q11, Q12 2SB596
Q13 2SC945A
Q14 2SD313
Q15 WZ-140
Q16 2SD313
Q17 2SA816

D1, D2 1S2473 x2
D3, D4 STV3H x2
D5, D6 W06A x2
D7~D10 ERC01-02 x4
D11~D14 1S1886 x4
D15 ZD15
D16 BZ-320
D17 1S2473 x2
D18 1S2473

PL1, PL2, PL3, PL4 DIAL IND 8V 300mA x3
PL5 8V 50mA STEREO IND

S1-a, S1-b POWER
S1 1/1F, S1 1/1R HEADPHONES 150mW/8Ω
S2 FUNCTION
S3 MODE
S4 a, b TAPE MONITOR 1
S5 a, b TAPE MONITOR 2
S6 LOUDNESS
S7 AC VOLTAGE SELECTOR
S8 1/2 F, S8 1/2 R, S8 2/2 F, S8 2/2 R

FU1 4A
FU2 4A
FU3 2A
FU4 6A
FU5 2A
FU6 2A

AC 220/240V 50/60Hz
SPEAKER A B 14V/8Ω