KP-5022

SPECIFICATIONS

DRIVE:	Direct Center-drive.
MOTOR:	D.C. Servo Motor (8 pole 24 slot).
TURNTABLE:	12 inch (30 cm) Solid die-cast aluminum alloy type.
SPEED:	Two speeds, 33-1/3 and 45 rpm.
WOW-FLUTTER:	Less than 0.05% (WRMS).
SIGNAL TO NOISE RATIO:	More than 58 dB.
SPEED CONTROL RANGE:	Within ±3% (Individual control for 33-1/3 and 45 rpm).
TONEARM:	Static Balance Type, Tapered pipe arm, Slide-locked EIA plug-in connector, Direct-reading stylus force gauge.
TRACKING ERROR:	±1.5 degree.
STYLUS FORCE VARIABLE RANGE:	0 to 4 grams.
CARTRIDGE:	
Type:	Moving magnet type.
Freq. Response:	20 Hz ~ 20,000 Hz.
Channel Separation:	More than 25 dB (1 000 Hz).
Output:	5 mV (1,000 Hz, 50 mm/sec).
Output Balance:	Less than 2.5 dB (1,000 Hz, 50 mm/sec).
Load Impedance:	50 K ohms.
Stylus Force:	2 ±0.25 grams.
Stylus:	0.6 mil Diamond.
Compliance:	7 x 10^{-6} cm/dyne.
Replacement Stylus:	Type N-39.
SPECIAL MECHANISM:	Auto-in. Auto-cut. Auto-repeat. Auto-return. Manual-in. Disc size selector. Pause elevation. Anti-skating force control. Head shell stand. Height and flexibility-adjustable large insulator. Pilotlamp for stylus adjust. 24 pole synchronous geared motor for arm drive.
SUPPLIED ACCESSORIES:	EP Adaptor. Low capacity audio cord with PIN plug.
POWER REQUIREMENT:	AC 110 ~ 120 V/220 ~ 240 V, 50/60 Hz.
POWER CONSUMPTION:	5 watts.
DIMENSIONS:	W 18 31/32" (482 mm), H 6-11/16" (170 mm), D 13-21/32" (347 mm).
WEIGHT:	19.8 lbs (9 kg).

www.hifiengine.com

KENWOOD

STEREO RECORD PLAYER

KP-5022 ①



Fig. No.	Parts No.	Description
1	G16-0047-02	Turntable sheet
2	D02-0012-05	Turntable
3	D19-0032-04	Trip pin
4	T43-0001-05	Motor
5	G13-0074-04	Insulator
6	L01-0207-05	Power transformer
7	N30-4008-11	Small pan head screw (M4 x 8)
8	F07-0302-04	Cover
9	K29-0159-04	Knob (Speed selector)
10	J20-0252-04	Switch mounting hardware (Speed selector)
11	S44-1004-05	Lever switch
12	K22-0034-04	Knob (Fine speed adjustment)
13	R01-1008-05	Potentiometer 1k (B)
14	N84-3006-41	Tap tight screw (M3 x 6)
15	N84-3008-41	Tap tight screw (M3 x 8)
16A	G01-0234-04	Floating spring (A)
16B	G01-0235-04	Floating spring (B)
16C	G01-0236-04	Floating spring (C)
17	G11-0036-04	Cushion
18	J91-0041-09	Tonearm (not included cartridge)
19	J91-0042-09	Arm
20	D91-0027-09	Main weight
21	J92-0012-09	Shell
22	T21-0034-05	Cartridge
23	N09-2610-09	Mounting screw
24	F07-0293-09	Stylus cover
25	A20-0639-05	Panel
26	J42-0056-04	Eccentric sleeve
27	J12-0063-04	Pin for tip
28	N15-1030-11	Washer (3.3ϕ x 8ϕ x 0.5t)
29	J09-0079-14	Shell stand
30	A20-0639-05	Dress sub panel assembly
31	A21-0147-02	Dress panel
32	B08-9006-04	Indicator
33	B42-0453-04	Dress panel name plate
34	–	–
35	D39-0022-14	Tonearm rest
36	J11-0029-14	Tonearm rest cramper
37	N08-0119-14	Dress screw
38	K29-0148-04	Knob (Pause)
39	B20-0269-04	Calibrations
40	K22-0033-04	Knob (Canceller)
41	N72-2002-11	Screw
42	D21-0310-03	Cam shaft
43	N19-0024-04	Insulating washer
44	G01-0218-04	Compression spring
45	D90-0014-00	Steel ball
46	N19-0080-00	Special washer
47	E39-0006-00	Tension wire
48	D10-0121-04	Canceller lever (A)
49	N09-0138-04	Special secrew
50	G01-0216-04	Tension spring (E)
51	B09-0004-04	Tonearm base cap
52	N73-4008-11	Screw
53	D01-0122-04	Canceller lever (B)
54	N14-0084-04	Special nut
55	K29-0147-04	Knob (Record size selector)
56	W01-0057-04	EP adapter
57	N09-0149-04	Special screw
58	J39-0101-04	Collar
59	D39-0023-14	Support assembly
60	–	–

Fig. No.	Parts No.	Description
61	N08-0119-14	Dress screw
62	D21-0300-04	Elevation shaft assembly
63	D21-0301-04	Elevation shaft
64	D29-0004-04	Tip for elevation shaft
65	J12-0068-04	Spring pin
66	N19-0018-04	Insulating washer
67	G01-0103-14	Compression spring
68	N19-0018-04	Insulating washer
69	N24-3050-60	E washer
70	D11-0178-04	Position arm assembly
71	D11-0179-04	Position arm calked assembly
72	G02-0048-04	Cross cam spring
73	N19-0082-00	Washer
74	N24-3030-60	E washer
75	N09-0094-04	Adjusting screw
76	G01-0135-04	Conical spring
77	G01-0141-04	Tension spring
78	D12-0054-04	Cross cam
79	N24-3020-60	E washer
80	N30-3006-11	Small pan head screw
81	D40-0155-13	Pause assembly
82	D49-0156-14	Pause chassis calked assembly
83	D11-0173-04	Elevation arm calked assembly
84	D10-0119-14	Pause lever calked assembly
85	G01-0220-14	Torsion spring
86	D23-0080-04	Bearing
87	N15-1040-11	Washer
88	G01-0110-24	Compression spring
89	N10-2040-11	Nut
90	G01-0222-14	Torsion spring
91	N30-2612-11	Small pan head screw
92	D21-0305-04	Elevation arm shaft
93	N24-3015-60	E washer
94	D10-0118-13	Right lever assembly
95	A10-0349-03	Right lever chassis
96	D11-0171-04	Repeat arm
97	D11-0172-04	Switch arm
98	G01-0219-14	Torsion spring
99	D21-0304-04	Arm shaft
100	N19-0143-04	Insulating washer
101	N19-0016-04	Insulating washer
102	G02-0047-14	Repeat lock spring
103	N30-2605-11	Small pan head screw
104	S46-1004-15	Leaf switch
105	S49-1005-05	Micro switch
106	N30-3016-11	Small pan head screw
107	N10-2030-11	Nut
108	K29-0145-04	Knob (PLAY/CUT)
109	K29-0146-04	Knob (REPEAT)
110	E15-0049-05	Vinyl tube
111	B30-0073-05	Neon tube
112	J19-0404-09	Slider
113	J25-0845-13	PC board
114	S51-1009-15	Relay
115	RW14AG3D471J	Resistor 470Ω 2W ±5%
116	CE02W1J101	Electrolytic capacitor 100μF 63WV
117	212-0027-05	Vinyl tube
118	V06C	Diode
119	PD14BY2E104J	Carbon resistor 100kΩ 1/4W ±5%
120	R90-0069-05	Ceramic based multiple component

Fig. No.	Parts No.	Description
121	–	–
122	E23-0047-04	PC board terminal
123	J19-0380-19	End cap
124	F01-0151-04	Heat sink
125	2SC1061 (C)	Transistor
126	CE04W1E101	Electrolytic capacitor 100μF 25WV
127	J25-0878-04	PC board
128	V06C	Diode
129	CE04W1E471	Electrolytic capacitor 470μF 25WV
130	E23-0046-04	PC board terminal
131	R12-0039-05	PC trimmer potentiometer 500Ω
132	WZ-061	Zener diode
133	PD14BY2E152J	Carbon resistor 1.5kΩ 1/4W ±5%
134	PD14BY2E102J	Carbon resistor 1kΩ 1/4W ±5%
135	PD14BY2E222J	Carbon resistor 2.2kΩ 1/4W ±5%
136	CE04W1E470	Electrolytic capacitor 47μF 25WV
137	N84-3006-41	Tap tight screw (M3 x 6)
138	N10-2030-11	Nut
139	N30-3010-11	Pan head screw
140	PD14BY2E102J	Carbon resistor 1kΩ 1/4W ±5%
141	PD14BY2E222J	Carbon resistor 2.2kΩ 1/4W ±5%
142	N15-1030-11	Washer
143	D40-0163-02	Auto mechanism assembly
144	D12-0051-24	EL cam calked assembly
145	N24-3020-60	E washer
146	D11-0112-04	Traveling arm calked assembly
147	G01-0133-04	Torsion spring (A)
148	N19-0153-04	Insulating washer
149	D12-0048-04	Off cam calked assembly
150	D40-0113-14	Adjust assembly
151	D32-0038-04	Stopper calked assembly
152	G01-0134-04	Tension spring (D)
153	J19-0185-14	Adjust calked assembly
154	N19-0157-04	Washer
155	N24-3025-60	E washer
156	D11-0114-24	Select arm calked assembly
157	N09-0094-04	Screw
158	G01-0135-04	Conical spring
159	G01-0136-14	Tension spring (C)
160	A10-0286-43	Mechanism chassis calked assembly
161	G02-0031-14	Leaf spring
162	N30-3005-11	Small pan head screw
163	D11-0120-04	Set off arm
164	G01-0137-04	Tension spring
165	S46-2006-55	Arm switch (C)
166	D11-0121-04	Connecting plate
167	D40-0116-04	Switch cam assembly
168	D12-0053-04	Switch cam
169	J21-0869-04	Bracket calked assembly
170	N87-2606-41	Tap tight screw
171	N24-3025-60	E washer
172	D11-0118-04	Detecting operation arm calked assembly
173	D40-0164-04	Detecting arm assembly
174	D11-0176-04	Detecting arm calked assembly
175	D29-0009-04	Tip
176	N24-3030-60	E washer
177	J31-0074-04	Sleeve
178	D11-0122-04	Return operation arm
179	N19-0025-04	Insulating washer
180	G01-0138-04	Torsion spring (D)

Fig. No.	Parts No.	Description
181	D11-0110-14	Muting arm
182	D11-0123-04	Hook arm
183	G01-0139-14	Torsion spring (B)
184	D11-0124-04	Switch arm
185	G01-0140-14	Torsion spring (C)
186	T41-0091-05	Timing motor
187	S46-2010-05	Arm switch (A1)
188	N30-2605-11	Pan head screw
189	S46-2011-05	Arm switch (D1)
190	N24-3040-60	E washer
191	D10-0116-14	Select lever calked assembly
192	N30-3008-11	Small pan head screw
193	–	–
194	E23-0016-04	Terminal lug
195	N84-4008-41	Tap tight screw
196	F07-0220-22	Protection cover (A)
197	N09-0097-00	Special screw
198	J21-1117-04	L shaped hardware
199	N84-4006-41	Pan head screw
200	A03-0117-01	Player case
201	F07-0318-04	Insulator cover
202	N14-0041-05	Nut
203	J03-0019-05	Insulator assembly
204	PARTS LIST	Cord stopper
205	PARTS LIST	Wood screw
206	PARTS LIST	Tap tight screw
207	PARTS LIST	Bottom board
208	PARTS LIST	Model name plate
209	E29-0050-05	Terminal board
210	J20-0267-04	Power transformer mounting hardware
211	N61-3110-11	Wood screw
212	J50-0049-15	Hinge (B)
213	PARTS LIST	Power transformer
214	N61-3112-12	Wood screw
215	PARTS LIST	Fuse
216	A02-0021-05	Player cover
217	J50-0049-05	Hinge (A)
218	N33-4008-13	Round head small pan head screw
219	PARTS LIST	Power cord
220	E30-0190-05	Audio cord
221	212-6008-05	Tube
222	J21-0511-04	Lead holder
223	PARTS LIST	Power voltage selector socket
224	G13-0002-04	Cushion
225	N15-1040-11	Washer
226	N30-4010-11	Small pan head screw
227	2SC945	Transistor
228	PARTS LIST	Power voltage selector plug
229	PARTS LIST	Power voltage selector cover
230	212-6505-05	Tube (6.5φ)
231	212-6008-05	Tube (5.8φ)
232	N19-0020-04	Insulating washer
233	B49-0047-04	Stroboscope sticker
234	J21-1164-04	Terminal board mounting hardware

Fig. No.	U.S.A. (K)	Canada (P)	PX (U)	Australia (X)	Europe (W)	England (T)	South Africa (S)	Other area (M)	Description
–	X31-1030-00	X31-1030-00	X31-1031-21	X31-1031-21	X31-1031-21	–	X31-1031-21	X31-1031-21	Panel assembly
–	N09-0068-00	N09-0068-00	N09-0068-00	N09-0068-00	N09-0068-00	–	N09-0068-00	N09-0068-00	Special screw (M4 x 16) x 3
–	N09-0149-04	N09-0149-04	N09-0149-04	N09-0149-04	N09-0149-04	–	N09-0149-04	N09-0149-04	Special screw (M4 x 35)
–	J09-0079-14	J09-0079-14	J09-0079-14	J09-0079-14	J09-0079-14	–	J09-0079-14	J09-0079-14	Shell stand
–	J31-0101-04	J31-0101-04	J31-0101-04	J31-0101-04	J31-0101-04	–	J31-0101-04	J31-0101-04	Collar (4.5ϕ x 7ϕ 18)
–	J91-0040-05	J91-0040-05	J91-0040-05	J91-0040-05	J19-0040-05	–	–	J91-0040-05	Pickup assembly
–	J91-0041-09	J91-0041-09	J91-0041-09	J91-0041-09	J91-0041-09	–	J91-0041-09	J91-0041-09	Tonearm
–	J91-0042-09	J91-0042-09	J91-0042-09	J91-0042-09	J91-0042-09	–	J91-0042-09	J91-0042-09	Arm (not include main weight and shell)
–	D91-0027-09	D91-0027-09	D91-0027-09	D91-0027-09	D91-0027-09	–	D91-0027-09	D91-0027-09	Main weight
–	J92-0012-09	J92-0012-09	J92-0012-09	J92-0012-09	J92-0012-09	–	J92-0012-09	J92-0012-09	Shell
–	T21-0034-05	T21-0034-05	T21-0034-05	T21-0034-05	T21-0034-05	–	–	T21-0034-05	Cartridge
–	N09-2610-09	N09-2610-09	N09-2610-09	N09-2610-09	N09-2610-09	–	–	N09-2610-09	Mounting screw (M2.6 x 10) x 2
–	F07-0293-09	F07-0293-09	F07-0293-09	F07-0293-09	F07-0293-09	–	–	F07-0293-09	Stylus Cover
–	X31-1010-03	X31-1010-03	X31-1010-03	X31-1010-03	X31-1010-03	–	X31-1010-03	X31-1010-03	Dress panel assembly
–	N84-3008-41	N84-3008-41	N84-3008-41	N84-3008-41	N84-3008-41	–	N84-3008-41	N84-3008-41	Tap tight screw (M3 x 8) x 6
–	X27-1020-11	X27-1021-01	X27-1020-21	X27-1020-21	X27-1020-61	–	X27-1020-21	X27-1020-21	Power supply unit
–	N84-3008-41	N84-3008-41	N84-3008-41	N84-3008-41	N84-3008-41	–	N84-3008-41	N84-3008-41	Tap tight screw (M3 x 8) x 3
–	X30-1020-00	X30-1020-00	X30-1020-00	X30-1020-00	X30-1020-00	–	X30-1020-00	X30-1020-00	Player case assembly
–	T43-0001-05	T43-0001-05	T43-0001-05	T43-0001-05	T43-0001-05	–	T43-0001-05	T43-0001-05	Motor
–	N30-4008-11	N30-4008-11	N30-4008-11	N30-4008-11	N30-4008-11	–	N30-4008-11	N30-4008-11	Small pan head screw (M4 x 8) x 3
–	X27-1030-00	X27-1030-00	X27-1030-00	X27-1030-00	X27-1030-00	–	X27-1030-00	X27-1030-00	Stabilized power supply unit assembly
–	N84-3008-41	N84-3008-41	N84-3008-41	N84-3008-41	N84-3008-41	–	N84-3008-41	N84-3008-41	Tap tight screw (M3 x 8) x 3
T1	L01-0207-05	L01-0207-05	L01-0207-05	L01-0207-05	L01-0207-05	–	L01-0207-05	L01-0207-05	Power transformer (power supply)
–	G13-0074-04	G13-0074-04	G13-0074-04	G13-0074-04	G13-0074-04	–	G13-0074-04	G13-0074-04	Insulator
–	N30-4010-11	N30-4010-11	N30-4010-11	N30-4010-11	N30-4010-11	–	N30-4010-11	N30-4010-11	Small pan head screw (M4 x 10) x 2
T2	L02-0049-05	L02-0058-05	L02-0049-05	L02-0049-05	L02-0049-05	–	L02-0049-05	L02-0049-05	Power transformer
–	J20-0267-04	J20-0267-04	J20-0267-04	J20-0267-04	J20-0267-04	–	J20-0267-04	J20-0267-04	Power transformer mounting hardware
–	N30-4008-11	N30-4008-11	N30-4008-11	N30-4008-11	N30-4008-11	–	N30-4008-11	N30-4008-11	Small pan head screw (M4 x 8) x 2
–	N15-1040-11	N15-1040-11	N15-1040-11	N15-1040-11	N15-1040-11	–	N15-1040-11	N15-1040-11	Washer (4.5 x 10 x 0.8t) x 2
–	N10-2040-11	N10-2040-11	N10-2040-11	N10-2040-11	N10-2040-11	–	N10-2040-11	N10-2040-11	Nut x 2
–	N61-3110-11	N61-3110-11	N61-3110-11	N61-3110-11	N61-3110-11	–	N61-3110-11	N61-3110-11	Wood screw x 5
–	–	–	E06-0706-15	E06-0706-15	E06-0706-15	–	E06-0706-15	E06-0706-15	Power voltage selector socket
–	–	–	E07-0304-15	E07-0304-15	E07-0304-15	–	E07-0304-15	E07-0304-15	Power voltage selector plug
–	–	–	N30-3006-11	N30-3006-11	N30-3006-11	–	N30-3006-11	N30-3006-11	Small pan head screw (M3 x 6) x 2
–	–	–	F07-0236-04	F07-0236-04	F07-0236-04	–	F07-0236-04	F07-0236-04	Power voltage selector cover
–	–	–	N30-3008-11	N30-3008-11	N30-3008-11	–	N30-3008-11	N30-3008-11	Small pan head screw (M3 x 8) x 2
–	K29-0147-04	K29-0147-04	K29-0147-04	K29-0147-04	K29-0147-04	–	K29-0147-04	K29-0147-04	Selector knob
–	K29-0148-04	K29-0148-04	K29-0148-04	K29-0148-04	K29-0148-04	–	K29-0148-04	K29-0148-04	Pause knob
–	F07-0302-04	F07-0302-04	F07-0302-04	F07-0302-04	F07-0302-04	–	F07-0302-04	F07-0302-04	Cover
–	K29-0159-04	K29-0159-04	K29-0159-04	K29-0159-04	K29-0159-04	–	K29-0159-04	K29-0159-04	Speed selector knob
–	K22-0034-04	K22-0034-04	K22-0034-04	K22-0034-04	K22-0034-04	–	K22-0034-04	K22-0034-04	Fine speed adjustment knob x 2
–	E30-0181-05	E30-0181-05	E30-0034-05	E30-0185-05	E30-0176-05	–	040-0304-05	E30-0034-05	Power Cord
–	J19-0259-04	J19-0259-04	J19-0259-04	J19-0345-04	J19-0345-04	–	J19-0345-04	J19-0259-04	Cord stopper
–	J41-0006-00	J41-0006-00	J41-0006-00	J41-0024-15	J41-0017-05	–	J41-0024-15	J41-0006-00	Cord bushing
–	E29-0050-05	E29-0050-05	E29-0050-05	E29-0050-05	E29-0050-05	–	E29-0050-05	E29-0050-05	Terminal board
–	N84-3010-45	N84-3010-45	N84-3010-45	N84-3010-45	N84-3010-45	–	N84-3010-45	N84-3010-45	Tap tight screw (M3 x 10) x 3
–	E30-0190-05	E30-0190-05	E30-0190-05	E30-0190-05	E30-0190-05	–	E30-0190-05	E30-0190-05	Audio Cord
–	E23-0016-04	E23-0016-04	E23-0016-04	E23-0016-04	E23-0016-04	–	E23-0016-04	E23-0016-04	Lug
–	G13-0002-04	G13-0002-04	G13-0002-04	G13-0002-04	G13-0002-04	–	G13-0002-04	G13-0002-04	Cushion x 2
–	N15-1040-11	N15-1040-11	N15-1040-11	N15-1040-11	N15-1040-11	–	N15-1040-11	N15-1040-11	Washer x 2
–	G16-0047-02	G16-0047-02	G16-0047-02	G16-0047-02	G16-0047-02	–	G16-0047-02	G16-0047-02	Turntable sheet
–	D02-0012-05	D02-0012-05	D02-0012-05	D02-0012-05	D02-0012-05	–	D02-0012-05	D02-0012-05	Turntable
–	D19-0032-04	D19-0032-04	D19-0032-04	D19-0032-04	D19-0032-04	–	D19-0032-04	D19-0032-04	Trip pin
–	B42-0453-04	B42-0453-04	B42-0453-04	B42-0453-04	B42-0453-04	–	B42-0453-04	B42-0453-04	Dress panel name plate
–	B40-0944-04	B40-0945-04	B40-0858-04	B40-0857-04	B40-0857-04	–	B40-0857-04	B40-0857-04	Model name plate
–	B49-0047-04	B49-0047-04	B49-0047-04	B49-0047-04	B49-0047-04	–	B49-0047-04	B49-0047-04	Stroboscope sticker
–	J21-1117-04	J21-1117-04	J21-1117-04	J21-1117-04	J21-1117-04	–	J21-1117-04	J21-1117-04	L shaped hardware x 2
–	N30-4008-11	N30-4008-11	N30-4008-11	N30-4008-11	N30-4008-11	–	N30-4008-11	N30-4008-11	Small pan head screw (M4 x 8) x 2
–	W01-0057-04	W01-0057-04	W01-0057-04	W01-0057-04	W01-0057-04	–	W01-0057-04	W01-0057-04	EP adoptor
–	H25-0078-00	H25-0078-00	H25-0078-00	H25-0078-00	H25-0078-00	–	H25-0078-00	H25-0078-00	Instruction bag
–	B50-1129-00	B50-1129-00	B50-1060-00	B50-1060-00	B50-1060-00	–	B50-1060-00	B50-1060-00	Instruction manual
–	B42-0009-04	B42-0009-04	B42-0009-04	B42-0009-04	B42-0009-04	–	B42-0009-04	B42-0009-04	Passed sticker
–	–	–	B58-0160-00	B58-0159-00	–	–	B58-0157-00	B58-0159-00	Power voltage selector caution card
–	J39-0021-05	J39-0021-05	J39-0021-05	J39-0021-05	J39-0021-05	–	J39-0021-05	J39-0021-05	Spacer
–	J39-0019-09	J39-0019-09	J39-0019-09	J39-0019-09	J39-0019-09	–	J39-0019-09	J39-0019-09	Spacer (A)
–	J39-0020-09	J39-0020-09	J39-0020-09	J39-0020-09	J39-0020-09	–	J39-0020-09	J39-0020-09	Spacer (B)
–	B58-0164-00	B58-0164-00	B58-0164-00	B58-0164-00	B58-0164-00	–	B58-0164-00	B58-0164-00	Shell caution card
–	–	–	B58-0139-00	B58-0003-00	–	–	B58-0003-00	B58-0003-00	Power supply caution card
–	–	–	–	–	B42-0262-24	–	–	–	SEV sticker
–	410-0001-00	410-0001-00	410-0001-00	410-0001-00	410-0001-00	–	410-0001-00	410-0001-00	DTE oil
–	410-0006-00	410-0006-00	410-0006-00	410-0006-00	410-0006-00	–	410-0006-00	410-0006-00	LUBRIPLATE AERO
–	410-0007-00	410-0007-00	410-0007-00	410-0007-00	410-0007-00	–	410-0007-00	410-0007-00	Silicone oil # 30,000
–	410-0009-00	410-0009-00	410-0009-00	410-0009-00	410-0009-00	–	410-0009-00	410-0009-00	Silicone oil #100,000
–	J21-0511-04	J21-0511-04	J21-0511-04	J21-0511-04	J21-0511-04	–	J21-0511-04	J21-0511-04	Lead holder
–	N84-3008-41	N84-3008-41	N84-3008-41	N84-3008-41	N84-3008-41	–	N84-3008-41	N84-3008-41	Tap tight screw (M3 x 8)
–	H01-0994-04	H01-0994-04	H01-0994-04	H01-0994-04	H01-0994-04	–	H01-0994-04	H01-0994-04	Carton case
–	H03-0247-04	H03-0247-04	–	H03-0247-04	H03-0247-04	–	H03-0247-04	H03-0247-04	Carton case
–	H10-0959-02	H10-0959-02	H10-0959-02	H10-0959-02	H10-0959-02	–	H10-0959-02	H10-0959-02	Polyethrene form fixture
–	H10-0960-02	H10-0960-02	H10-0960-02	H10-0960-02	H10-0960-02	–	H10-0960-02	H10-0960-02	Polyethrene form fixture
–	H10-0961-04	H10-0961-04	H10-0961-04	H10-0961-04	H10-0961-04	–	H10-0961-04	H10-0961-04	Protection board
–	H10-1029-03	H10-1029-03	H10-1029-03	H10-1029-03	H10-1029-03	–	H10-1029-03	H10-1029-03	Polyethrene form fixture
–	H10-1030-13	H10-1030-13	H10-1030-13	H10-1030-13	H10-1030-13	–	H10-1030-13	H10-1030-13	Buffer fixture
–	H20-0382-04	H20-0382-04	H20-0382-04	H20-0382-04	H20-0382-04	–	H20-0382-04	H20-0382-04	Protection cover
–	H25-0029-04	H25-0029-04	H25-0029-04	H25-0029-04	H25-0029-04	–	H25-0029-04	H25-0029-04	Protection bag x3
–	J61-0021-05	J61-0021-05	J61-0021-05	J61-0021-05	J61-0021-05	–	J61-0021-05	J61-0021-05	Vinyl tie
–	–	–	–	J61-0036-05	J61-0036-05	–	J61-0014-05	–	Free-up belt
–	B46-0021-00	B46-0021-00	B46-0022-00	–	–	–	–	–	Warranty card
–	–	–	B46-0023-00	–	–	–	–	–	Warranty card
–	–	–	B42-0368-04	–	–	–	–	–	EP sticker
–	B58-004300	B58-0043-00	–	–	–	–	–	–	Carton case caution card
–	B42-0420-04	B42-0420-04	–	–	–	–	–	–	Caution sticker
–	B42-0431-04	B42-0431-04	–	–	–	–	–	–	Caution sticker
–	B58-0182-05	B58-0182-05	–	–	–	–	–	–	Caution sticker
–	F19-0126-05	F19-0126-05	–	–	–	–	–	–	Sticker
–	–	–	B59-0018-00	–	–	–	–	–	KENWOOD service stations' list

KENWOOD

STEREO RECORD PLAYER

KP-5022

POWER SUPPLY (X27-1020-11)

STABILIZED POWER SUPPLY (X27-1030-00)

Q1 : 2SC1061(C), Q2,3 : 2SC945, D1,2 : V06C, D3 : WZ-061

(L02-0049-05)

P TYPE
K TYPE

M TYPE
U TYPE
W TYPE
X TYPE
S TYPE
T TYPE

AC 117V 60Hz

AC 110-120V 220-240V 50/60Hz

M1	DIRECT DRIVE MOTOR
M2	TIMING MOTOR
T1,2	POWER TRANS.
S1	PLAY/CUT SWITCH
S2	ARM SWITCH (C)
S3	ARM SWITCH (A)
S4	ARM SWITCH (D)
S5	MICRO SWITCH
S6	SPEED SELECTOR

Qc1,2,4,5 : 2SC828, Qc3,6~8 : 2SA564
Qc9~11 : 2SC1346, ZDc1 : RD6A(M)
Dc1 : MA26, Dc2,7 : KB265C4
Dc3~6 : DS410, Dc8~13 : OA-91

<MOTOR CIRCUIT>