



Ⓑ Only



TONE SELECTOR TREBLE	F-2544	S01a, b	1. 1.5kHz 2. DEFFAT 3. 3kHz
TONE SELECTOR BASS	F-2544	S02a, b c, d	1. 300Hz 2. DEFEAT 3. 150Hz
SPEAKERS SELECTOR	F-2547	S01a, d	1. OFF 2. A 3. B 4. C 5. A+B 6. A+C

Note:

1. In model Ⓑ, the section in ⬚ on schematic diagram above are not installed.
2. Each voltage in parentheses ( ) shows the value of model Ⓑ in volts.