"DYNAMIC CORRECTION" MODULE

"THESE COMPONENTS ON OUTPUT PCB AOP1"

OUTPUT BOARD "AOP1"

4×5" 8Ω SPEAKERS.

IN PHASE OUT SWITCH (ON BACK PANEL)

TR1 = J112
TR2 } BF423
TR3 }
TR4 } BF422
TR5 }
TR6 } BF422
IC1 = TL071
D1 TO D4 = IN4148
D5 TO D10 = IN4148
D11 TO D4 = IN5402

EARTH
NEUTRAL
LIVE
FUSE
MAINS SWITCH
VOLTAGE SELECTOR 115
EARTH LIFT
To CHASSIS
TRANSFORMER. TR10
IN540A

PL3

5v SUPPLY
ANALOG GROUND
SIG OUT "R"
-12v SUPPLY
SIG OUT "L"
DIGITAL GROUND
NOT USED.
SIGNAL IN
+12v SUPPLY

TOP VIEW

PL2 AND PL4

1 0 PRE EQ D.I.
2 0 +5v
3 0 DIGITAL GND
4 0 ANALOG GND
5 0 Fx RETURN
6 0 Fx SEND
7 0 POST EQ D.I. AND LINK
8 0 +
9 0 +30v
10 0 REVERB MUTE SIGNAL