
V1 ECC83/12AX7
V2 ECC83/12AX7
V3 ECC83/12AX7
V4 ECC83/12AX7
V5 ECC83/12AX7
V6 ECC83/12AX7
V7 7591
V8 7591
V9 7591
V10 7591
S1 SECTION I FRONT
S1 SECTION I REAR
S2 FRONT
S2 REAR
S3 EQUALIZATION SWITCH
S4 HIGH FILTER SWITCH
S5 TAPE MONITOR SWITCH
S6 LOUDNESS CONTOUR SWITCH
S8 FRONT
S8 REAR
S9 FRONT
S9 REAR
S10
S11
S12
T1
T2
T3
REC A OUTPUT
MON A INPUT
REC B OUTPUT
MON B INPUT
TREBLE CONTROL
BASS CONTROL
VOLUME CONTROL
BALANCE CONTROL
DIMENSION CONTROL
METER
NEON LAMP
105-120 VOLTS 50-60 CYCLES AC
CHANNEL A BIAS
CHANNEL B BIAS
S8 INPUT SELECTOR SWITCH POSITIONS
SHOWN IN → MAG 1
MAG 2
TUNER
AUX 1
AUX 2
S8 MODE SWITCH POSITIONS
SHOWN IN → MONO PHONO
REVERSE
STEREO
A
B
S8 CENTER SPEAKER LEVEL SWITCH POSITIONS
SHOWN IN → OFF
LOW
MEDIUM
HIGH
MAX
S9 METER SWITCH POSITIONS
SHOWN IN → OFF
BIAS A
BAL A
BIAS B
BAL B