



FAT THOR ML

19-november-05
 updated: 06-november-07
 inspired by diyAudio.com
 tweaked by Scottmoose
 drawn by did

Placement of brace (just off centre). Notch the brace to accommodate the drivers. Mid-woofer magnets should fit tightly to notch. Brace needs to be filled with random holes with the goal of 35-50% open space.

optional additional bracing (just off centre). Brace needs to be filled with random holes with the goal of 35-50% open space.

"pedestal" required to lift terminus free (and raise tweeter closer to listening level) or run the port out the back or side

NOTES:

- 1/ drawn with 3/4" (19mm) material
- 2/ 0.75 lbs / ft³ (12 g / litre)
- 3/ 3" D, 4" long port (75mm x 102mm)
- 4/ corner reflectors non-critical

