



Notes by bjorno:
Line walls w/ $\geq 1/4"$ wool felt in the areas where the damping material is applied (see: Post #12).

Use stuffing as indicated:
.134kg[4.73oz] from S1 to S2, and
.055kg[1.94oz] from S2 to S3.

Driver:
Goldwood GW-12PC-4
(The driver outline in the drawing is from a LAB12.)
Material: 3/4" MDF (.750")

S1 Recalculated to make up for mouth center divider (brace).



Bill_C_Goldwood_TL.dwg