

Line Amp

- 1) Set Volume control fully counter-clockwise (minimum). Set BASS and TREBLE controls at mid-position (flat). MUTE button should be out.
- 2) Monitor the output with a DC oscilloscope as unit is turned on. Turn-on voltage should not exceed 50 mV. Final output voltage should not exceed 20 mV.
- 3) Alternately engage and disengage MUTE while adjusting the offset control near phono for minimum change in DC output. Reset MUTE button to the out position.
- 4) Twist BASS control while observing the change in DC output voltage. Adjust offset control near transformer for minimal change as BASS control is twisted.
- 5) Reset BASS control to mid-position and repeat step (3).
- 6) Repeat steps (1) through (5) for second channel.

Rodney E. Wood 3-13-79
Project Engineer Date

Ran Fischer 3/13/79
Engineering Mgr. Date

[Signature] 3/13/79
Vice Pres of Engrg. Date

Revisions Date

