



SV1 / SV2

PC97 : jumper on 2-3

PC900 : jumper on 2-1

V2
PC97 / PC900

V3
PC97 / PC900

SV3

ECC82 jumper on 1-2

6N1P jumper on 2-3

Based on Merlin Blencowe book:
Designing High-Fidelity Tube
Preamps

PC97 RIAA Preamp

09/06/2017 10:10:46

Sheet: 1/1