



Adjust P2/ R7 and P3/ R13 to 90 Ohm  
 ground gate of T1-T4, T9 - 12  
 lift point A from ground  
 adjust A to ground to 0V  
 wire the circuit back  
 adjust DC offset after T7 / T8 to + - 5mV with P2  
 fine adjust Offset with P4  
 OP1, OP2, OP3 decoupled with 220uF, 1u, 10n  
 T1 / T2 = 2SK170BL  
 T3 / T4 = 2SJ74  
 T5 / T8 = BF446A  
 T7 / T8 : selected for Hfe