



Transistors turned around plus offset adjust. 2 x 150pF could be connected after transistors

Input DC Offset adjust

R3, R9 lowered to 290 Ohm so that more current flows 10mA per input transistor and 4mA through R7, R8

T1 !PNP
T2 !NPN