



PULSE(0 4 650µ 100n 100n 50µ 425µ 1)
PULSE(0 4 100µ 20µ 400µ 50µ 400µ 1)

To look at gain and phase margins:
i) comment the .tran line
ii) uncomment the .ac line
iv) re-run the simulation
iii) plot V(A)/V(B)

K1 L2 L3 1
.tran 800µ

.options maxstep=10u

.fourier 1K V(a) <- To see the output of a .four statement, select View=>Spice Error Log

.ac oct 10 1 100Meg

This example schematic is supplied for informational/educational purposes only.