



WIRING INSTRUCTIONS

1. Install the DPDT switch between the left and right speaker binding posts.
2. Install the headphone jack on the left side of the front panel.
3. Disconnect LEFT and RIGHT positive speaker connections and connect to the common terminals of the DPDT switch.
4. Connect all resistors as shown near the DPDT toggle switch.
5. Connect the two speaker (-) binding posts together with the t-pad array grounds, then run a common ground wire to the star ground point.
6. Route the left and right signal wires from the resistor t-pad arrays to the headphone jack. Keep the wires to the left side of the chassis.
7. Run the ground for the headphone jack to the star ground point.