

The Kansas City Shuffle

By Tom Johnson

All resistors 2 watt
unless noted

Build Amplifier with 8 pin tube sockets for input and phase inverter tubes. install 3 - 9 pin tube sockets for input and phase inverter tubes with pin 9 attached.

