



External dimensions:
H=28
W=24
D=22
Driver:
B&C 18TBX100

Use 1x1 bracing (3/4" x 3/4") in all internal corners. Broce top to bottom w/ 2x2 (1-1/2" x 1-1/2"), and side to side twice w/ 2x2. Apply polyfill botting to three internal sides, e.g.: bottom, one side, back. Fold the botting to give you at least two inches loose thickness.