



Adjustment:

1. Open Switch A
2. Send a low level 125 Hz sine signal to both amps.
3. Measure V_o' with an AC multimeter
4. Adjust the volume of the pot [V] such that $V_o = V_o'$ with same AC multimeter
5. Close switch A. There should be No change in V_o'

Compound Amp A3.pdf

Antenual

8/31/12