



Fig. 15.2: The safety-earth bond should be made to a dedicated screw, close to the mains inlet.