

Folded Horn Acoustic Guitar Old School 12-8-23



No CNC for the soundboard screws. Measure and put the screws in the body. Put the top on the screws, tap with a rubber mallet, you have your locations as indents, then drill. Old School spotting technique!