

Back to the HOMs

- Since the HOMs in a waveguide travel at a slower speed along the axis of the waveguide (they are dispersive) they will have a substantially greater group delay than the main mode.
- These group delayed modes become more audible with greater HOM level, greater delays (higher order) and at higher SPL levels.