



10) MAKE SURE WIRES ARE IN PLACE ,  
THEN FLOOD WIRE RACES WITH GOOP .  
DO NOT DISTURB UNTILL DRY . (4-5 HRS)

11) TEASE POLY-FILL ,THEN PALCE EVENLY  
IN CABINET . 15-OZ . IN FRONT CHAMBER AND  
9-OZ . IN REAR .

12) PLACE FOAM TAPE AROUND THE BOTTOM  
PERIMETER OF THE BASE PLATE .  
INSTALL BASE WITH DRY-WALL SCREWS .

