

BIAS ADJUSTMENT:

SELECT R8 FOR 100mV OVER R23
START AT ZERO OHMS,
INCREASE TO 200-300 OHMS

LOWER GAIN:

INCREASE R7 TO 1K,
DECREASE C3 TO 220/25

LOWER RAIL VOLTAGE:

DECREASE R27 TO MAINTAIN
ZENER REGULATION

DO NOT SUBSTITUTE IC1!

MUST BE A FET TYPE,
MUST WORK FROM SINGLE -12V,
IS NOT IN THE SIGNAL PATH, SO
NOTHING TO BE GAINED REALLY!

