

Easy to set idle  
VAS current dependent on RMe  
Low temp dependency

Lower RL renders circuit biasing less critical and less temp dependent  
5k or 3k THD20 is unchanged

.step param RL LIST 1k 3k 5k  
.param RL 3k

.temp 70

.param RMe 86  
.param BCR 200k

