



Q6 and Q8 on heatsink for tracking
current feedback resistors R24 and R28 between 4k7 and 6k8 dependent of amplification
and cathode resistor R34
amp is a test, it can be a good
one free for forum.

C16 to prevent overshoot, with 120pF you
have a very nice blockwave of 30 KHz.

Electronics Workbench 891-111 Peter Street Toronto, ON M5V 2H1 (416) 977-5550			NATIONAL INSTRUMENTS ELECTRONICS WORKBENCH GROUP	
Title: transistor tube	Desc.: Current Feedback			
Designed by: C Upelaar	Document No: 0001	Revision: 1.0		
Checked by: C Upelaar	Date: 2011-01-11	Size: D		
Approved by: C Upelaar	Sheet 1 of 1			