



Duct height @:

S1=5.221"

S2=3.629

S3=2.797

S4=2.696

L12=55.610

L23=74.410

L34=7

Stuffing:

Fiberfill @ .5lbs/ft²

Lining in the top 180° turn, and around the back of the woofer.

Fill volume ~ 1.34ft³

Fiberfill weight ~ .7lbs.

Density should be highest around S1, and taper off towards the driver (S2) area.

Derived from T-TQWT by bjorno for permo:
here: Single driver TB W8Q-1071D

