

First, power up without JP6 & JP7 and adjust the +15V with P5
 Then adjust the symmetry with P6 to match the -15V to the +15V
 Supply voltages are available on JP6 & JP7 when jumpers are off
 Don't short JP6 or JP7 while measuring voltages
 Ground is readily available everywhere on the board with ground planes
 Before putting JP6 & JP7 on, make sure to power off and wait a short while
 to discharge the caps, put JP6 & JP7 on then power up if the +-15V supplies
 are properly set. Don't let uneven voltages go in the circuit

