


# !! WARNING !! LETHAL VOLTAGES PRESENT



OPERATION  
WHEN AMP POWER SWITCH IS OPEN CURRENT FLOWS TO AMP RECEPTACLE

WHEN AMP POWER SWITCH IS CLOSED POWER IS REMOVED FROM AMP RECEPTACLE AND "CAP DISCHARGE" RELAY IS CLOSED CONNECTING CAPS THOUGH RESISTOR TO GROUND

INSULATE ALL EXPOSED VOLTAGES  
USE COMPONENTS RATED FOR APPROPRIATE VOLTAGES AND CURRENT  
CONCEPT PRESENTED AS IS - USE AT YOUR OWN RISK

Title		
AUTO CAP DISCHARGE		
Size	Document Number	Rev
A	NON-COMMERCIAL USE ONLY	0
Date:	Friday, December 07, 2012	Sheet 1 of 1