

To Main Board

To 5v/Gnd

Remote Receiver

Button or Remote

Debounce

Down

Mute

Input Sel

Display PC Board

Unused Gates

