



KK1 Driver heatsink KK2 Driver heatsink 2

Blas servo must be installed between output transistors, on the heatsink

Drivers should have small heatinks installed between output transistors, heatinks are included in the DXAMP.com transistor kit

www.DXAMP.com

TITLE: DXHRII\_amp\_Sch\_Ve

Document Number:

Date: 2007/10/21 12:41:28p

Sheet: 1/1

REV: E