

Items marked as OPTIONAL should not be used by default - see instructions. Don't populate caps and use 0R for resistors.