


# INPUT & ERROR AMPLIFIER



# COMPARATOR

# OUTPUT STAGE



# +5V / -5V SUPPLY

# GATE DRIVE SUPPLY



PROTECTION  
PROT.sch

DO NOT POPULATE R18 AND R21  
IF AUX SUPPLY IS PROVIDED VIA J12,

Title		
Size	Number	Revision
A4		
Date:	21-Oct-2011	Sheet of
File:	C:\PAANIC\audio\AMPS\DA25\DA25.qd	Drawn By:

- TP77 RANOCCHIA
- M1 CORNER POST-UP POSTUP
- M2 CORNER POST-UP POSTUP
- M3 CORNER POST-UP POSTUP
- M4 CORNER POST-UP POSTUP