



right channel no output when picked at dump
 replaced blue components and right channel had output
 problem observed after right channel components replaced both right and left have same audio. Not stereo? Determined by turning analog balance knob to either right or left and there was sound from both the right and left.

3/10/2015 pulled main jacks. connected CD player into amp inputs.
 sound out of both channels. Disconnect right or left CD input and there was sound coming out of both the right and left. Same with headphones.

visually observed that R200 was badly discolored. Attempt to measure insitu measured open.

Measured TP- / TP+ on right channel 0.000mV

Measured DC offset on right 83mV and left 90mV