


Modified on 09/24/03

SKW-30 Subwoofer Parts List

EAMOSKW30P	Pre-Amp with Harness. Order with,	}
1216SKW30	Frequency Selector Knob	
511SKW30	Volume Knob	
ELP2219	+/_ Lead Set	
EAMOSKW30	Amplifier assembly	
EW61615P	EW61615P Woofer	
EAC3M1C	RCA Cable	
12K / 3watt carbon	Resistor (obtain Locally)	
EAMOSKW30-1	Power Block Only.	



Note: *It is important to remove the knobs with care as not to damage front cabinet assembly. When replacing any components on the pre-amplifier assembly it may be necessary to replace the knobs that may be damaged as well.*

1216SKW30	Frequency Selector Knob
511SKW30	Volume Knob
EAC3M1	RCA cable
SKF110W	Fuse AGC 2A 250V

SKW-30 Subwoofer Amplifier

