



IC1		
DFRduino Nano		
	D1	VIN
	D0	GND
	Reset	RESET
	GND	+5V
	D2	A0
	D3	A1
	D4	A2
	D5	A3
	D6	A4
	D7	A5
	D8	A6
	D9	A7
	D10	AREF
	D11	3V3
	D12	D13
USB Mini		

U3

