



Figure 387. The monitor output connections.

There are nine monitor outputs available on BNC connectors on the 2700 series front panel. The monitor outputs are intended for external oscilloscope, spectrum analyzer or other monitoring. These outputs are not calibrated and should not be used for measurements.

Refer to the manual *Getting Started with Your 2700 Series Instrument* for detailed input and output specifications. See Chapter 4, **Signal Inputs and Outputs** for more information about the 2700 series main inputs and outputs and the software panels associated with them.