

Series TNT200

USER GUIDE



Thank you for your purchasing our Woofer.

Our product is the one of advanced science and technology, which can bring you wonderful and perfect prolong audio entertainments.

To optimize its functions while you operating the unit and for your safety, you should read attentively this manual and retain the manual for future reference.

All the packing materials should be reserved for reusing if the unit needs sending to the maintenance shop in the future. You should also please fill in the table below, which is helpful also if the unit needs maintaining in the future.

TNT200 Woofer	
Purchasing date: _____	Intaller: _____
Unit No.: _____	Distributor's No.: _____
Setting up date: _____	Distributor's add.: _____

Brief introduction

ACOUSTAT TNT200 is an originate passive Sub-woofer specially designed for AC-3/DTS Digital Theatre, which can fully satisfy the need of reproduction of quality ultra low acoustic frequency in Hi-Fi and Home Theatre. It adopts ACOUSTAT exclusive composite metal cone and special 8" f0 professional sub-woofer plastic edge unit, along with powerful linear magnetic circuit structure, with the features of long linear stroke, clear reproduction effect, vigorous ultra low frequency with abundant sub-woofing sense, avoiding the disadvantages of unclear, fuss, bad sense of gradation, messy, building up solid and accurate acoustic field, living up to the extreme requirement of sub-woofer by Hi-Fi fans, and it is applicable both in Home Theatre and Hi-fi appreciation. Along with the hi-tech HI-FI design by ACOUSTAT's electro-acoustic expert, you may casually experience the unprecedented vigor of power.

System: TNT200 Woofer	Power: 100W
Impedance: 8 Ω	Sensitivity: 85dB/m/w
Frequency range: 32Hz~250Hz	

Connection Layout

- 1、 Firstly, turn off the general power switch of the amplifier.
- 2、 Take out the accessory speaker connection wires with care
- 3、 Connect the speaker wires between the positive and negative poles of the amplifier and TNT200 Woofer respectively.
- 4、 Connect the wires of the static speakers to the positive and negative output poles in TNT200 Woofer.



TNT200 Woofer

