

Frequency	Mid panel voltage	Voltage %	Ribbon voltage	Voltage %
6Khz	2.32v	--	2.28v	--
10Khz	1.942v	84	1.902v	83
12Khz	1.908v	82	1.869v	82
14Khz	1.872v	81	1.835v	80
16Khz	1.834v	79	1.793v	79
18Khz	1.780v	77	1.741v	76
20Khz	1.704v	73	1.674v	73
25Khz	1.400v	60	1.383v	61
30Khz	0.929v	40	0.873v	38