


5V EXTERNAL POWER CONNECTION


TOP VIEW



Above shown Resistor to be removed (to isolate sbc power from boss power) before connecting external power on J4 connector.

BOTTOM VIEW

Assemble 0E Resistor 0805



Above shown Resistor to be assembled Value: 0E 0805 Package