



CAW/ENTEC I2f Printed Circuit Assembly

Connector Pinouts

Line In Connector

- 1 LED+
- 2 LED-
- 3 KEY
- 4 Ground
- 5 R Ch. Out
- 6 L Ch. In-
- 7 L Ch. In+
- 8 R Ch. In+
- 9 R Ch. In-
- 10 L Ch. Out
- 11 BP Filter In

Notch Connector

- 1 Slave Out
- 2 Ground
- 3 Notch On/Off In
- 4 KEY
- 5 Notch On/Off Out
- 6 Notch Freq In
- 7 Notch Freq Out
- 8 Bass Boost Out
- 9 Bass Boost In

Power Connector

- 1 V-
- 2 Ground
- 3 V+

Speaker Connector (3 ea)

- 1 Speaker -
- 2 Speaker +

Changes

Rev B 1/92

- 1) Add 220uH and .1uF from U601-4 to gnd
- 2) Delete C620
- 3) Change R627 to 1.0K
- 4) Change R629 to 4.75K
- 5) Change C614 to .1uF

Rev C 8/11/92

- 1) Change R114, R214, R302 to 2.49K

Rev D 11/10/92

- 1) Change R115, R215 to 475 Ohm
- 2) Change R304 to 47.5K

N.B. R627; adj to 1K ohms for servo stability.