

NOTES

1. Resistor values are indicated in ohms unless otherwise specified (K=1,000 M=1,000,000)

2. Capacitor values are indicated in microfarads unless otherwise specified (pico=picofarads)

F101	TRANS/FUSE VALUE
KS	T 220V 60HZ
	F SB200mA/250
D	T
	F
A	
P.T	

NOTES

1. Resistor values are indicated in the following table. Values not specified in the table are standard values.

Resistor Value	Color Code
1-1000 M Ω	1-0000 (blue)
2. Capacitor values are indicated in alphanumeric values unless otherwise specified (pico=picofarads)	

CAUTION

Exercise caution to use following instructions to avoid damage to the circuit:

- 1. Do not touch the parts marked with the caution symbol.
- 2. Do not use the parts marked with the caution symbol in the parts list.
- 3. After returning the kit to the customer, make appropriate leakage tests to determine the exposed parts are properly insulated from the supply circuit.

