

# 7. SCHEMATIC DIAGRAM 7-1. Audio Section

- SWITCHES & CONTROLS**
- POWER/SPEAKERS** F-3066
- LOUDNESS** F-3062
- TAPE MONITOR** F-3062
- FM MUTING/FM MONO** F-3062
- SUBSONIC FILTER** F-3062
- SELECTOR** F-3062
- BALANCE** VR<sub>01</sub> F-3065
- VOLUME** VR<sub>01a,b</sub> F-3066
- BASS** VR<sub>03a,b</sub> F-3066
- TREBLE** VR<sub>02a,b</sub> F-3066
- VOLTAGE SELECTOR** 100, 120, 220, 240V
- 1. POWER OFF**
- 2. A SYSTEM**
- 3. SPEAKER OFF**
- 4. B SYSTEM**
- 5. A+B SYSTEMS**
- 1. OFF**
- 2. ON**
- 1. SOURCE**
- 2. TAPE**
- 1. ON/STEREO**
- 2. OFF/MONO**
- 1. OFF**
- 2. ON**
- 1. AUX**
- 2. PHONO**
- 3. FM**
- 4. AM**

- SYMBOL**
- △ Ceramic
- △T Ceramic (Temperature Compensation)
- △F Ceramic (Feed Through)
- Low-Leak Electrolytic
- (B.P) Bi-Polar Electrolytic
- (Ta) Tantalum Electrolytic
- ⊙ Mylar
- ⊙ Polystyrene
- ⊙ Fusing Resistor
- ⊙ Non-Inflammable Resistor
- ⊙ Cement Resistor

