







Multi-Voltage Transformer Strapping Diagram GFA-555



5A Fuse = 220V
 10A Fuse = 120V
 USE APPROPRIATE SIZE FUSE

front panel