Schematic Diagram ..... Model ST-3500 (This schematic diagram may be modified at any



Notes:

S1-1~S1-5 : Selector switch in "FM MONO" position
FM MONO ⇔ FM STEREO ⇔ FM AUTO ⇔ AM
S2-1~S2-3 : Muting/AFC switch in "OFF" position
{MUTING) ..... OFF ⇔ 1 ⇔ 2 (DEEP)
[(A F C) ..... OFF ⇔ AUTO ⇔ AUTO
S3-1~S3-4 : Delay time switch in "CONST" position CONST ⇔ HI-LAG
S4 : MPX hi-blend switch in "OFF" position OFF ⇔ ON
S501-1~S501-2 : Power source switch in "ON" position
S502 : Voltage selector switch in "110V" position
110V ⇔ 120V ⇔ 220V ⇔ 240V
DC voltage measurements are taken with VTVM from chassis ground
( ) ..... FM stereo signal reception
{ } ..... Muting switch to ON position and FM mono (or stereo) signal reception
No Mark ..... Muting switch to ON position and FM/AM non-signal reception