











Direct from
Soundcard







Connect to Mic-Preamplifier
for SPL Measurements



Switch
On for calibration
Off for Impedance
On for SPL



Or if you need
amplification



Amp
Receiver

