

THE LEFT CHANNEL ONLY SHOWS COMPONENTS FOR THE RIGHT ARE NUMBERED
R10R,C10R,D10R,Q10R etc.
P2,R10R,D10R and C10R ARE MOUNTED EXTERNALLY TO THE PC BOARD
* SHOWS COMPONENTS USED TO GENERATE THE MAX EQUALIZATION.
THE COMPONENTS SHOULD BE USED
** SOLDERED ON THE REAR OF THE PC BOARD.

