


Parts marked with the symbol  in the schematic diagram have critical characteristics. Use ONLY replacement parts recommended by the manufacturer. It is recommended that the unit be operated from a suitable DC supply or batteries during initial check-out procedures.

**WARNING:**

**NOTE:** Description of electrolytic capacitor:  $100/16V = 100\mu 16V$

