


INPUT & ERROR AMPLIFIER

COMPARATOR

OUTPUT STAGE





5V SUPPLY

5V RAIL SPLITTER

GATE DRIVER SUPPLY

NOTE: POP. EITHER
L1 OR L1A
L2 OR L2A



PROTECTION
PROT.sch

- M1 CORNER POST-UP POSTUP
- M2 CORNER POST-UP POSTUP
- M3 CORNER POST-UP POSTUP
- M4 CORNER POST-UP POSTUP

Title		
Size	Number	Revision
A4		
Date:	6-Sep-2011	Sheet of
File:	C:\PAANIC\audio\AMPS\DA25\DA25.d	Drawn By: