



### MECHANICAL PARTSLIST

1	4822 459 05099	FRONT ASSY CDR765 BLACK /xx
1	4822 459 05103	FRONT ASSY CDR765 GREY /xxS
3	4822 410 12024	KEY UNIT MIDDLE ASSY BLACK /xx
3	4822 410 12025	KEY UNIT MIDDLE ASSY GREY /xxS
9	4822 410 11962	POWER BUTTON BLACK /xx
9	4822 410 11964	POWER BUTTON GREY /xxS
14	4822 459 10887	WORDMARK logo
15	4822 454 13339	CDRW - LOGO
65	4822 459 05101	TRAY FRONT LEFT ASSY BLACK /xx
65	4822 459 05104	TRAY FRONT LEFT ASSY GREY /xxS
81	4822 691 10737	CDR LOADER CDL3610/01
115	4822 459 05102	TRAY FRONT RIGHT ASSY BLACK /xx
115	4822 459 05105	TRAY FRONT RIGHT ASSY GREY /xxS
131	4822 691 10742	CD LOADER UNIT L1265/51
165	4822 442 01506	COVER
251	4822 462 42159	FOOT SILVER
252	4822 462 42159	FOOT SILVER
253	4822 462 42158	FOOT BLACK
254	4822 462 42158	FOOT BLACK
301▲	4822 321 10249	SBC1201 MAINS CABLE EUROPE
301▲	4822 321 10939	MAINS CORD USA
312	4822 321 11357	AUDIO CORD SET
313	4822 321 11357	AUDIO CORD SET
317	4822 321 61452	DIG OUT CABLE L=1000M M RCA
318	4822 219 10559	REMOTE CONTROL RC07110/01
1001	4822 214 12825	CDR MAINBOARD CDR765
1002▲	4822 218 11938	POWER SUPPLY 20PS314/00
1002▲	4822 218 11967	POWER SUPPLY 20PS314/17