



Main power supply board



ch1

ch2

ch3









ch10

Mixer + out-put board - vocal section


Mixer + out-put board - instrument right section

Mixer + out-put board - instrumenta left section

Mixer + out-put board - bass section



channel 1 preamplifier board



heater supply

25.2+2.0 = 27.2v

V1 V2 V3 V4

channel 2 preamplifier board

V1 V2 V3 V4

channel 3 preamplifier board

V1 V2 V3 V4

channel 10 preamplifier board

V1 V2 V3 V4