

PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	CODE	REF. NO.	PART NO.	DESCRIPTION	CODE
R25	VRD-SU2EY123J	12K ohm	**	034	91Z891452-1	Friction Rubber	**
R26	VRD-SU2EY392J	3.9K ohm	**	035	91Z895585	Plate, Main Gear	**
R27	VRD-SU2EY333J	33K ohm	**	036	91Z871208	Bracket, Operation	**
R28	VRD-SU2EY123J	12K ohm	**	037	91Z871209	Push Switch Ass'y	**
R29	VRD-SU2EY102J	1K ohm	**	038	91Z891092	Pin, Auto Return Arm	**
R30	VRD-SU2EY562J	5.6K ohm	**	039	91Z895688	Button, Push Switch	**
R31	VRD-SU2EY331J	330 ohm	**	040	91Z895588	Lever, Reject	**
R32	VRD-SU2EY101J	100 ohm	**	041	91Z895589	Lever, Start	**
R33,				042	91Z891443	Spring, Start Lever	**
R34,	VRD-SU2EY223J	22K ohm	**	043	91Z895590	Lever, Repeat	**
R35,				044	91Z870066	Arm, Auto Return	**
R36				045	91Z892809-1	Bracket, Bottom Cover	**
R37,						Retaining	**
R38	VRD-SU2EY272J	2.7K ohm	**	046	91Z895586	Operation Plate	**
R39	VRS-PT3DB4R7K	4.7 ohm, 2W, ±10%, Oxide Film	**	047	91Z892940-1	Rubber	**
R40	VRD-SU2EY222J	2.2K ohm	**	048	91Z895587	Ring, Operation Plate	**
R41,	VRD-SU2EY103J	10K ohm	**	049	91Z846367-4	Cabinet	**
R42				050	91Z846368-2	Bottom Cover	**
R101	VRD-SU2EY123J	12K ohm	**	051	91Z896387	Leg	**
R102	VRD-SU2EY103J	10K ohm	**	052	91Z890238-6	Bracket, Bottom Cover	**
R103	VRD-SU2EY123J	12K ohm	**			Retaining	**
R104	VRD-SU2EY273J	27K ohm	**	053	91Z895691	Plate, Leg	**
R105	VRD-SU2EY103J	10K ohm	**	054	91Z895967	Screw, Leg Retaining	**
R106	VRD-SU2EY393J	39K ohm	**	055	91Z851097-3	Dust Cover	**
R107	VRD-SU2EY562J	5.6K ohm	**	056	91Z895231	Plate, Hinge	**
R108	VRD-SU2EY222J	2.2K ohm	**	057	91Z895215	Hinge Ass'y	**
R109	VRD-SU2EY224J	220K ohm	**	058	91Z620026	Turntable	**
R110	VRD-SU2EY154J	150K ohm	**	059	91Z871160	Sheet, Turntable	**
R111	VRS-PT3DB822K	8.2K ohm, 2W, ±10%, Oxide Film	**	060	HBDGD3054AFSA	Badge, OPTONICA	AC
R112	VRD-SU2EY123J	12K ohm	**			(91Z893820)	**
MISCELLANEOUS				061	91Z890876	EP Adaptor	**
001	91Z871189	Power Circuit Ass'y	**	062	91Z895218	Shield, Output P.W. Board	**
002	91Z892484	Tube, Insulator	**	063	91Z891568-2	Bushing, Mains Supply Cord	**
003	91Z895758	Connector Ass'y	**			(BS)	**
004	91Z704151-1	Socket, Power	**		91Z891568-3	Bushing, Mains Supply Cord	**
005	91Z895591	Bracket, Lamp/Volume	**			(KEMA)	**
006	91Z702233-3	Tube, Insulator	**	064	91Z851319-1	Pick-up Ass'y (Without	**
007	91Z895733	Connector, Ass'y	**			Cartridge)	**
008	91Z631318	Motor Ass'y	**	065	91Z851227	Sub-chassis Ass'y	**
009	91Z631347	Control Circuit Ass'y	**	066	91Z870317	Main Gear Ass'y	**
010	91Z894989	Bracket, Power Transformer	**	067	91Z891431	Switching Lever Ass'y	**
		Retaining	**	068	91Z891951	Clutch Lever Ass'y	**
011	91Z895734	Bushing, Power Transformer	**	069	91Z891016-1	Switching Lever Ass'y	**
012	91Z895735	Plate, Power Transformer	**	070	91Z891435	Select Arm Ass'y	**
		Retaining	**	071	91Z891437	Select Guide Lever Ass'y	**
013	91Z894408	Holder, Wire	**	072	91Z870172	Rotation Plate Ass'y	**
014	91Z893327	Insulator, Micro Switch	**	073	91Z870157	Start Lever Ass'y	**
015	91Z895157	Insulator, Micro Switch	**	074	91Z891444	Lever, Repeat	**
016	91Z890755	Holder, Wire	**	075	91Z891474	Spring, Clutch Lever	**
017	91Z892618	Knob, Speed Fine Adjust	**	076	91Z891438	Spring, Select Arm	**
018	91Z895592	Cover, Lamp	**	077	91Z891475	Spring, Safety	**
019	91Z895595	Holder, Lamp	**	078	91Z891443	Spring, Start Lever	**
020	91Z893037	Plate, Output Lead Hold	**	079	91Z891445	Bushing	**
021	91Z895596	Plate, Voltage Selector Switch	**	080	91Z893566	Spring, Repeat Lever	**
022	91Z891568-4	Bushing, Output Lead	**	081	91Z895720	Shaft, Eccentric	**
023	91Z895155-1	P.W. Board, Output Lead	**	082	91Z891947	Spring, Clutch Lever	**
024	91Z895154-1	Bracket, P.W. Board Retaining	**	083	91Z891022	Spring, Rotation Plate	**
025	91Z893699-1	Output Lead Ass'y	**	084	91Z890095	Shaft, See-saw Lever	**
026	91Z894509-6	Earth Lead Ass'y	**	085	91Z894937	Tip, Switching Lever	**
027	91Z896293	Select Lever Ass'y	**	086	91Z891785	See-saw Lever Ass'y	**
028	91Z895594	Lever, Select Lever Ass'y	**	087	91Z895721	Screw, Auto Read-in Mechanism	**
029	91Z895593	Lever, Selector	**			Adjust	**
030	91Z700508-1	Spring, Select Lever	**	F101	QFS-C201CAGNI	200mA/250V	**
031	91Z891482	Arm Control Lever Ass'y	**	F102	QFS-C801CAGNI	800mA/250V	**
032	91Z801553	Spring, Arm Control Lever	**	F103	QFS-C320CAGNI	32mA/250V	**
033	91Z813681	Spring, Screw Lock	**	PL101	91Z895757	Neon Lamp	**

PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	CODE	REF. NO.	PART NO.	DESCRIPTION	CODE
SW1	Not available	Speed Selector Switch	N-A		QACCV0001AGZZ	Mains Supply Cord (KEMA)	AP
		Part of 037			(91Z892280)		
SW101	QSOCE0551AFZZ	Switch, Voltage Selector	AG		TINSL0138AFZZ	Operation Manual	**
		(91Z871207)			TTAGH0058AFZZ	Tag	**
SW102,	91Z895430-1	Switch, Power	**				
SW103	QACCB0052AF09	Mains Supply Cord (BS)	AM				
		(91Z895961)					